

LEVEL UP BRACKET INSTALLATION

<p>Step 1: Prep</p>	<ul style="list-style-type: none"> • Excavate to plus or minus 1/2 inch from grade • Prep pad with 2-4" of gravel per IRC and IBC Code • Level plus or minus 1/2 inch and square project site
<p>Step 2: Place and install Mono Slab® EZ Form</p>	<ul style="list-style-type: none"> • Beginning at a corner, place the first EZ form in position to a rough level- extending the form past the corner • Place the next Mono Slab® butting it in firm contact with • the previous form and repeat • Connect forms with 2x8x8' or 2x12x8', staggering the seams • Secure the forms with two stakes per 8' length
<p>Step 3: Backfill</p>	<ul style="list-style-type: none"> • Lightly backfill the exterior up to the bottom of the lumber covering all EPS foam • Starting at the highest point in the foundation, lift the screed board to perfect level • Secure screed boards with Level Up Extension Brackets. • Place EPS extension level with the screed board and secure the forms using two stakes per form. • At screed board intersections, fasten butt joints using 3-3 inch grabber screws. Fill any gaps with expandable foam between extension piece and Mono Slab® EZ Form.
<p>Step 4: Pour</p>	<ul style="list-style-type: none"> • Prepare and pour the interior slab.

